




COOKTOP PARTS

For Models: RS696PXGB0, RS696PXGQ0
(BLACK) (DESIGNER WHITE)

30" ELECTRIC
DROP-IN RANGE
SELF CLEANING
OVEN



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

COOKTOP PARTS


For Models: RS696PXGB0, RS696PXGQ0
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
NOTE: The screws and nuts required to attach a part are listed immediately following that part.			5	3191791	Spring, Locator	16		Limiter, Temperature
				246119	Screw (8)		3191990	Use W/3191984 Element
			7		Switch, Infinite		3191988	Use W/3191982 Element
				3191049	1200W RR-LR (Silver Shaft)		3191991	Use W/3191983 Element
1		Trim Ring, Cooktop		3191050	1800W RR (Yellow Shaft)	17	3192452	Frame, Cooktop (2)
	4449978	Black		4454541	2500W LF (Red Shaft)	21	3191952	Lamp, Indicator
	4449979	White		311865	Screw		3191953	Bumper, Rubber
2	4168863	Screw (10)	8	3183956	Seal, Switch Cover		9750835	Bumper, Door
		Cooktop, Glass	10		Knob, Control (4)			
	3191188	Black		3196231	Black			
	3191189	White		3196232	White			
3	3191310	Bracket, Switch Mounting	14	3182435	Seal, Switch (4)			
4		Element, Surface	15	3191515	Bracket, Support Element			
	3191984	1200W RF-LR						
	3191982	1800W RR						
	3191983	2500W LF						

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: RS696PXGB0, RS696PXGQ0
(BLACK) (DESIGNER WHITE)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN PARTS

For Models: RS696PXGB0, RS696PXGQ0
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1		Trim, Side (Right Hand)
	4450844	Black Model
	4449747	Screw
	4450845	White Model
	4449041	Screw (Left Hand)
	4450847	Black Model
	4449747	Screw
	4450848	White Model
	4449041	Screw
4	4448520	Bumper, Door
7	4452237	Top Chassis
	4449809	Screw
9	4452158	Tube, Vent
	4449154	Screw
10	4452165	Lens, Light
11	4452368	Oven Light Assy

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

12	4452166	Bulb, Light
14	4451740	Frame, Front
	4449040	Screw
	4450118	Nut
15	4449372	Gasket, Door
19	4451478	Support, Insulation
	4449809	Screw
21		Rail, Side
	4450579	Right Side
	4450580	Left Side
	4448444	Grommet
	4449154	Screw
22	4451424	Latch Assy
23	4451663	Solenoid
24	4451422	Micro Switch N.C.
	4449809	Screw
25	4454691	Side, Chassis (R.H. & L.H.)
	4449809	Screw
26	4452234	Back, Chassis
	4449809	Screw
27		Liner, Oven (Not serviceable)
28	4451426	Micro Switch

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

29	4451665	Sensor
	4449154	Screw
30	4451537	Spring, Latch
37	4451442	Thermostat (TOD) (Temp.) SPST
43	4451398	Base, Chassis
49	4448933	Retainer, Gasket
	4449154	Screw
50	4451747	Cover, Back
	4449809	Screw
53	4449845	Support, Bracket
	4449809	Screw
55		Trim, Bottom
	4448477	Black Model
	4448478	White Model


FOLLOWING PARTS NOT ILLUSTRATED

INSULATION

4449316	Insulation, Wrap
4450365	Insulation, Back

CONTROL PANEL PARTS

For Models: RS696PXGB0, RS696PXGQ0
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

- | | |
|---------|--|
| 1 | Control Panel Assy.
W/Membrane Switch |
| 4451231 | Black Model |
| 4451232 | White Model |
| 4449745 | Screw |
| 4159465 | Screw |
| 2 | 4451034 Gasket,
Control Panel |
| 3 | 4452240 Microcomputer |
| | 4449745 Screw |
| | 3149333 Screw |


LITERATURE PARTS

- | | |
|------------|------------------------------|
| LIT3191800 | Installation
Instructions |
| LIT3191537 | Use & Care Guide
(Oven) |
| LIT3192239 | Tech Sheet (Oven) |
| LIT3191638 | Safer Cooking Tips |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OVEN DOOR PARTS

For Models: RS696PXGB0, RS696PXGQ0
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451719	Door Liner
2	4454947	Hinge, Door
	4449743	Screw
3	4449259	Glass, Inner

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

4	4451722	Insulation, Door
7	4449263	Glass, Inner
9	4451668	Retainer, Glass
	4449809	Screw
13		Door Handle
	4448854	Black Model
	4448855	White Model
14	4450813	Bracket, Handle
	4451040	Screw
15		Assy, Door Glass
	4452065	Black Model
	4452066	White Model


Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

19	4450362	Shield, Heat
	4449809	Screw
20	4451671	Retainer, Glass
	4449809	Screw
21	4451674	Seal, Door Top
23		Retainer, Clip
	4450863	Black Model
	4450864	White Model
	4449743	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP VENTING PARTS

For Models: RS696PXGB0, RS696PXGQ0
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------


NOTE: The screws and nuts required to attach a part are listed immediately following that part.

1	4451759	Vent, Exhaust
	4449040	Screw
2	4451438	Elbow, Vent-Top
3	6610168	Blower
4	4451758	Block, Foam
5	4451752	Elbow, Vent-Bottom
11	4449868	Block, Terminal
	3196181	Screw
13	4448549	Vent, (Control Panel)
	4450038	Screw
14		Side, Control Compt.
	4451535	Right
	4451536	Left
	4449809	Screw
15	4452244	Back, Control
	4449809	Screw
20	3191842	Cover, Rear
21	4451407	Plate, Support

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

INTERNAL OVEN PARTS

For Models: RS696PXGB0, RS696PXGQ0
(BLACK) (DESIGNER WHITE)



Illus. No.	Part No.	DESCRIPTION
2	4452154	Element, Broil
	4449154	Screw
3	3147563	Grill, Broiler
4	3147845	Pan, Broiler
6	4448717	Rack, Oven
7	4452153	Element, Bake
	4449154	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

OPTIONAL PARTS

For Models: RS696PXGB0, RS696PXGQ0
(BLACK) (DESIGNER WHITE)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

PAINT, TOUCH-UP (1/2oz.)

	72017	White
	261869	Cord Brown
	72032	Black

PAINT, SPRAY

	350930	White
	261900	Citrine White
	830864	Black

ADHESIVE

	591014	Adhesive Loctite (1/3 oz.)
	482338	Sealer, Silastic (3 oz.)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

SPLICING WIRES---25FT.

LENGTH

	242828	Wire (12 Ga. 150 c Black)
	242820	Wire (14 Ga. 150 c Black)
	242821	Wire (14 Ga. 150 c Blue)
	242822	Wire (14 Ga. 150 c Brown)
	242830	Wire (14 Ga. 200 c Brown)
	242823	Wire (14 Ga. 150 c Green)
	242824	Wire (14 Ga. 150 c Orange)
	242829	Wire (12 Ga. 150 c Red)
	242825	Wire (14 Ga. 150 c Red)
	242831	Wire (14 Ga. 200 c Red)
	242826	Wire (14 Ga. 150 c White)
	242827	Wire (14 Ga. 150 c Yellow)
	242832	Wire (14 Ga. 200 c Yellow)

Illus. No.	Part No.	DESCRIPTION
------------	----------	-------------

WIRING HARNESS PARTS

	4454918	Harness, Wire (Main)
	3191956	Harness, Wire (Infinite Switch)
	3192168	Harness, Wire (Burners)
	313438	Clip, Harness
	3179589	Wire, Tie
	4451163	Conduit
	4448664	Clamp
	4449809	Screw
	112432	Nut
	4450800	Screw, Ground
	4451761	Support, Wiring
	4454842	Tie, Cable
	4452222	Spacer, Harness

Miscellaneous

	814381	Pin Hinge Kit
	4448950	Screw, Install (4)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST